

On Mold Prevention and Control



- Fix leaky plumbing and leaks in the building envelope as soon as possible.
- Watch for condensation and water stains.
- 3 Fix sources of moisture problems as soon as possible.
- Prevent moisture caused by condensation by increasing surface temperature or reducing the moisture level in the air (humidity).
- 5 Improve air flow to decrease moisture by opening windows or adding a fan.
- Keep heating, ventilation and air-conditioning drip pans clean, flowing properly, and unobstructed.
- Vent moisture-generating appliances, such as dryers, to the outside where possible.
- Maintain low indoor humidity, below 60 percent relative humidity (RH), ideally 30 to 50 percent, if possible.
- 9 Perform to a regular schedule of building/HVAC inspections and maintenance.
- Provide drainage outside foundation walls and slope the ground away from the foundation to speed drying after rainfalls.

